



JE1029BMK Troubleshooting Guide

Unit will not power ON

- Confirm 12V+ power on the power harness.
- Confirm Ground on power harness.
- Check vehicle's fuse where monitor receives power.

No Picture

- Verify external source is connected to video input.
- Verify external source is turned ON.
- Try a different video cable.
- Try a different video source.