



VCCYL35 Troubleshooting Guide

No image on monitor

- Verify camera cable connection at monitor is good.
- Verify camera is connected to camera cable.
- Connect camera directly to monitor if possible.
- Connect known good camera & cable to monitor.

Flickering or rolling Image

- Switch to secondary camera input on monitor.
 - If image is stable, replace monitor.
- Check for 12V+ to monitor.
- Connect known good camera & cable to monitor.
 - If image is stable, check camera/cable.
 - If image still flickers/rolls replace monitor.

No color

- Verify monitor supports color feature.
- Verify proper lighting.
- Connect known good camera.