



## VCCYL35 Troubleshooting Guide

### **No image on monitor**

- Verify camera cable connection at monitor is good.
- Verify camera is connected to camera cable.
- Connect camera directly to monitor if possible.
- Connect known good camera & cable to monitor.

### **Flickering or rolling Image**

- Switch to secondary camera input on monitor.
  - If image is stable, replace monitor.
- Check for 12V+ to monitor.
- Connect known good camera & cable to monitor.
  - If image is stable, check camera/cable.
  - If image still flickers/rolls replace monitor.

### **No color**

- Verify monitor supports color feature.
- Verify proper lighting.
- Connect known good camera.