



JHD1130 Troubleshooting Guide

Radio will not turn ON

- Try the reset button.
- Check fuse.
- Confirm 12V+ on the Turn ON ACC+ wire to radio (RED wire).
- Confirm Ground.

Radio turns ON, but no sound

- Verify **Volume, Fader/Balance, Mute** controls are set correctly (see owners manual).
- Try RESET button.
- Verify mode is active (CD, AUX, AM/FM, etc.)
- Verify proper speaker connections.
- Check for shorts or opens on speaker wires.

No AM, FM or WB reception

- Verify you are tuned to a valid station.
- Check your antenna connection on rear of stereo.
- Try a different antenna.
- Verify tuner Area is set to correct region: USA, Europe

No audio in AUX mode

- Verify audio cable is connected securely to radio and source.
- Test with different audio cable.
- Verify volume level on source is turned all the way up.

Unit does not respond to Remote Control (optional)

- Verify that you have a clear line of sight for the IR signal.
- Check the batteries. Replace as needed.
- Test remote for operation by viewing LED through digital camera view screen while pressing remote buttons. The LED should blink rapidly. A cell phone camera will work to perform this test of the remote control.

Clock does not maintain correct time after installation.

- The radio has a capacitor to maintain the clock when the vehicle loses power for up to 30 days. Once the radio is installed, the capacitor must have time to energize. Typically this takes around 20 minutes. Leave radio with power applied for 20 minutes after installation to charge the capacitor.

01.31.13