INSTALLATION

MOUNTING SCREWS
(INSTALL BEFORE GRILLE)

SIDE CLIPS
(2X EACH SIDE
TOP/BOTTOM)

GRILLE
(INSTALL LAST)

INSERT ENDS FIRST

END CLIPS
(2X EACH END)

GILLE INSTALLATION:
1. PRESS AND SECURE END CLIPS FIRST
2. CAREFULLY SQUEEZE AND WORK TOWARD
   MIDDLE TABS, PRESSING IN AS YOU GO

30.15
RECOMMENDED CUTOUT 30.30

RIGHT AUX IN
RED FEMALE
RCA CONNECTOR

LEFT AUX IN
WHITE FEMALE
RCA CONNECTOR

YELLOW
(+12V BATTERY)

7.5 AMP MINI TYPE
FUSE W/ HOLDER

RED
(12V TRIGGER)

BLACK (GND)

*CONNECT RED 12V TRIGGER TO BLUE TRIGGER OF RADIO

4.29
RECOMMENDED
CUTOUT
4.415