

JHDHBC Wired Remote Installation Instructions


Introduction

Thank you for choosing a Jensen product. The JHDHBC universal handlebar control allows convenient operation of compatible Jensen radios including volume adjustment, mode selection and basic functions of available sources such as AM/FM tuner, Weather Band, Bluetooth, USB, iPod/iPhone, SiriusXM satellite radio.

Installation

Installation method is shown as diagram.



1. Kit Includes 2pcs M4 x 8 Mounting Screws and 6pcs Cable Ties".
2. Custom mounting brackets sold separately.



Wiring

Once the remote has been mounted, route the cable from the remote and connect the cable to the radio. Note the connector polarity on the extension cable.

Important: When connecting the cables, be sure to route the extension cable away from sharp objects, corners, and places where it might get pinched, as this could affect performance and cause damage to the unit.



VIEW A-A
SHOWN FROM PIN VIEW

| PIN NO. | FUNCTION |
|---------|----------|
| 1 | VOLUME + |
| 2 | VOLUME - |
| 3 | MUTE |
| 4 | GROUND |
| 5 | TUNE + |
| 6 | TUNE - |
| 7 | MODE |
| 8 | GROUND |



ASA Electronics Corporation
www.asaelectronics.com
www.jensenheavyduty.com

©2017 ASA Electronics Corporation
 v.200417

Operation

| Control | Action | Standby | Tuner | USB MP3 | iPod iPhone | AUX | Bluetooth | SiriusXM | Weather Band |
|---------|--------|---------|---|-----------------------|-----------------------|-----------------------|-----------------------|-----------------------|-----------------------|
| VOL+ UP | Press | — | Volume Increase | Volume Increase | Volume Increase | Volume Increase | Volume Increase | Volume Increase | Volume Increase |
| | Hold | — | Rapid Volume Increase | Rapid Volume Increase | Rapid Volume Increase | Rapid Volume Increase | Rapid Volume Increase | Rapid Volume Increase | Rapid Volume Increase |
| VOL- DN | Press | — | Volume Decrease | Volume Decrease | Volume Decrease | Volume Decrease | Volume Decrease | Volume Decrease | Volume Decrease |
| | Hold | — | Rapid Volume Decrease | Rapid Volume Decrease | Rapid Volume Decrease | Rapid Volume Decrease | Rapid Volume Decrease | Rapid Volume Decrease | Rapid Volume Decrease |
| << | Press | — | Tune Down | Previous Track | Previous Track | — | Previous Track | Step Tune Down | Previous Station |
| | Hold | — | Tune Seek Down | Rewind | Rewind | — | — | Rapid Channel Down | — |
| >> | Press | — | Tune Up | Next Track | Next Track | — | Next Track | Step Tune Up | Next Station |
| | Hold | — | Tune Seek Up | Fast-Forward | Fast-Forward | — | — | Rapid Channel Up | — |
| MUTE | Press | — | Mute Unmute | Mute Unmute | Mute Unmute | Mute Unmute | Mute Unmute | Mute Unmute | Mute Unmute |
| MODE | Press | — | Press the MODE button on the control panel to select a different mode of operation, Available modes include Tuners, iPod, USB, AUX In, BT and SXM | | | | | | — |



ASA Electronics Corporation
www.asaelectronics.com
www.jensenheavyduty.com
 ©2017 ASA Electronics Corporation
 v.200417